

## 4. Boot Setup Menu

AMIBIOS SETUP UTILITY - VERSION 3.31a					
Main	Advanced	Security	Power	Boot	Exit
<div>Quick Boot Mode <b>Enabled</b></div> <div>Boot Up Num-Lock <b>On</b></div> <div>Boot To OS/2 <b>No</b></div> <div>Boot From Network <b>Disabled</b></div> <div><b>VIA SATA Raid Utility</b> <b>Enabled</b></div> <div>▶ Boot Device Priority</div>				<div>[ Setup Help ]</div> <div>&lt;Enter&gt; to enable or disable the quick boot mode.</div>	
F1:Help Esc:Exit			↑↓:Select Item ←→:Select Menu		+/-:Change Values Enter:Select   ▶Sub-Menu
					F9:Setup Defaults F10:Save & Exit

### Quick Boot Mode

Enable this mode will speed up the boot-up routine by skipping memory retestings.

### Boot Up Num-Lock

If this is enabled, it will automatically activate the Numeric Lock function after boot-up.

### Boot To OS/2

This enables boot-up to OS/2 operating system.

### Boot From Network

Use this to enable or disable “boot from network” feature.

### VIA SATA Raid Utility

Use this to enable or disable VIA VT8237 SATA Raid BIOS Utility during POST.

### Boot Device Priority

This allows you to set the boot device priority.